

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Filter Pads

Fryer type: Dean MF 80/90

Pad type: SuperSorb® Carbon Pad F-38 (Pad size: 16.25" x 18.25" / 41.28 x 46.35 cm)



GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- Carbon Pad has always to be placed into the pan with "bumpy side" up.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Place the filter on top of the screen ensuring the smooth side is facing down and the bumpy side faces up. Place the ring on top of the filter.



STEP 2

Make sure to tighten the handles from the ring to the sides of the machine. Reconnect the hose to the machine.



STEP 3

Using a metal spatula, gently remove crumb debris from the top of the filter, this will help oil flow through the filter for daily 2nd filtration as well as removal of the filter.



STEP 4

Disconnect the hose from the machine and set aside, then remove the ring from the top of the filter and set aside.



STEP 5

Remove the used filter and discard.



STEP 5

Remove the bottom of the machine. Rinse and clean out the bowl only using HOT water at the side area or mop sink.