

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Filter Pads

Fryer type: Frymaster (Built-in) FootPrint III Filtration System
Pad type: SuperSorb® Carbon Pad F-54

GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- Carbon Pad has always to be placed into the pan with "bumpy side" up.
- O-Rings (3) on frying oil return valve need to be checked every 3–4 months (worn or missing O-Rings have a negative effect on oil pumping back through the Carbon Pad) .
- Please do not use any filter-powders in addition to the SuperSorb Carbon Pad.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Open the fryer doors and pull the filter pan out. Remove weight ring, but leave the screen in place at the bottom of the well.



STEP 2

Insert the F-54 Carbon Pad into the pan with the bumpy side up. The Carbon Pad will fit "edge to edge."



STEP 3

Insert the hold down ring and press it firmly into place. Finally, insert the crumb catcher.