

# INSTALLATION INSTRUCTIONS

## SuperSorb® Carbon Filter Pads

**Fryer type:** Henny Penny Open Vat & Pressure Fryer  
**Pad type:** SuperSorb® Carbon Pad



### GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- Carbon Pad has always to be placed into the pan with "bumpy side" up.
- Always use a new CarbonPad every day.
- After filtering carefully scrape the crumb debris off the Carbon Pad using a spatula or putty knife.
- Please do not use any filter-powders in addition to the SuperSorb Carbon Pad.
- Always wear protective apparel or refer to your companies OPS.



### STEP 1

After removing the original filter screen and filter assembly from the Henny Penny filter tank, replace with FILTROX (Filtercorp) Unifit Adapter Kit #752 which includes the Carbon Pad base with handle, 17" NSF hose, and coupler fitting.



### STEP 2

Be sure to place Carbon Pad with rough side facing out, smooth side against the adapter base screen support.



### STEP 3

Make sure 17" Hose is tightly screwed onto the Carbon Pad base and coupler fitting. The Carbon Pad Adapter is now ready to screw into the Henny Penny wing nut coupler.