

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Filter Pads

Fryer type: Frymaster PF 50

Pad type: SuperSorb® Carbon Pad F-20B (Pad size: 12.375" × 17.375" / 31.43 × 44.13 cm)



GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- Carbon Pad has always to be placed into the pan with "bumpy side" up.
- Please do not use any filter-powders in addition to the SuperSorb Carbon Pad.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Place the support screen in the center of the previously cleaned and dried pan.



STEP 2

Insert the F-20B Carbon Pad into the pan with the bumpy side up (smooth side down).



STEP 3

Insert the existing hold down ring and press it firmly into place.



STEP 4

When needed, scrape the crumb debris off the Carbon Pad before continuing the oil filtrations. Removing crumb debris will help oil flow back to the fryer vats. Use one Carbon Pad and replace at start of each day.