

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Filter Pads

Fryer type: Pitco Bloomin Brands

Pad type: SuperSorb® Carbon Pad F-87 (Pad size: 19.16" × 19.16" / 48.58 × 48.58 cm)



GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- Carbon Pad has always to be placed into the pan with "bumpy side" up.
- O-Rings in good condition help create a tight seal to the pipe arm and FILTROX Carbon Pad filter.
- Please do not use any filter-powders in addition to the SuperSorb Carbon Pad.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Be sure the filter pan is clean and completely dry of water. Place the screen on the bottom of the pan.



STEP 2

Check Pitco Stainer Cap and clean off any crumb debris.



STEP 3

Insert the F-87 Carbon Pad into the pan with the bumpy side up (smooth side down).



STEP 4

Insert the existing hold down ring and press it firmly into place.



STEP 5

For multiple filtrations, when filter pan has cooled, using a spatula scrape crumb debris off the Carbon Pad as shown in photo. Removing crumb debris will improve oil flow through the filter and back to fryer.



STEP 6

Preventative maintenance includes replacing the O-Ring which is located inside the Pickup pipe opening usually once a year.