

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Filter Pads

Fryer type: RF Hunter Portable Filter Machine – Starter Kit# 723-40
Pad type: SuperSorb® Carbon Pad

GENERAL INFORMATION

- Make sure the filter-pan is clean and dry and to remove any existing screens, paper holders, etc from the filter pan.
- Carbon Pad has always to be placed into the pan with “bumpy side” out.
- Please do not use any filter-powders in addition to the SuperSorb Carbon Pad.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Locate the front of the pump housing. Remove the 1046 coupling from the housing pump pipe. Install the 1/2" 90 degree elbow (part# 867) and the 1/2" male quick disconnect (part# 1013).



STEP 2

The FILTROX (Filtercorp) Unit adapter (part# 1001-40) will have a flexible stainless steel hose (part# 1064) with a bushing (part# 1007), 1/2" female quick disconnect part (#1016) and standard handle (part# 1005).



STEP 3

Place the FILTROX (Filtercorp) Unifit into the RF Hunter pan so that it sits flush with the bottom of the pan. Connect the female quick disconnect on the end of the hose with the male quick disconnect located on the pump housing.