

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Envelope

Fryer type: Vulcan
Pad type: SuperSorb® Carbon Envelope F-70



GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- Please do not use any filter-powders in addition to the SuperSorb® Carbon Envelope.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Be sure all screen parts are clean and dry before assembly.



STEP 2

Carefully insert screen support into the Carbon Envelope. Close the sealing flap and be sure to position the holes of the Carbon Envelope filter equal to the screen support.



STEP 3

Insert the coupler screw through the bottom and top of the envelope filter.



STEP 4

Attach the coupler suction pipe and screw tightly so the pipe end is pointed the opposite direction of the sealing flap.



STEP 5

Use the metal sealing bar and place over the paper sealing flap.



STEP 6

Place assembled the Carbon Envelope into the Vulcan filter pan and position the crumb basket on the left side.