

INSTALLATION INSTRUCTIONS

SuperSorb® Carbon Filter Pads

Fryer type: DarPro Fry Oil Filter Machine

Pad type: SuperSorb® Carbon Pad F-24 (Pad size: 11.25" × 19.16" / 28.58 × 49.78 cm)

GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- No powder additives are needed with the FILTROX Carbon Pad.
- Dispose and replace a new Carbon Pad every day.
- After filtering carefully scrape the crumb debris off the Carbon Pad using a spatula or putty knife.
- Wash FILTROX (Filtercorp) Unifit Adapter with hot water and set to dry completely.
- Always wear protective apparel or refer to your companies OPS.



STEP 1

Remove the DarPro support screen and hold down bar from the filter tank.



STEP 2

Install the FILTROX (Filtercorp) F-16 Unifit Adapter Kit inside the filter tank with carbon pad (rough side facing down) into the filter tank.



STEP 3

Connect FILTROX (Filtercorp) Unifit flex hose's quick disconnect part to the DarPro pick up hose's female quick disconnect. (The filter tank hose will not be used.)



STEP 4

Place DarPro crumb basket in front of the filter tank as normal. The read tank cover will not be used with this conversion.