

# INSTALLATION INSTRUCTIONS

## SuperSorb® Carbon Filter Pads

**Fryer type:** Pitco Solo Built In Filtration System  
**Pad type:** SuperSorb® Carbon Pad F-24

### GENERAL INFORMATION

- Make sure the filter-pan is clean and dry.
- FILTROX (Filtercorp) F-16 Unifit Adapter includes the filter base, flex hose and a new fitting.
- After filtering, crumb debris may need to be scraped clean. Allow the F-16 Unifit to cool before scraping the Carbon Pad with a spatula.
- Always wear protective apparel or refer to your companies OPS.



#### STEP 1

The Pitco Solstice Built-In Filter Machine needs to be adapted to use FILTROX (Filtercorp) F-16 Unifit Adapter Kit.



#### STEP 2

After the Pitco Paper holder has been removed, insert the FILTROX (Filtercorp) F-16 Unifit Adapter Kit so that it sits flush on the bottom of the pan.



#### STEP 3

After filtering, crumb debris may need to be scraped clean. Allow the F-16 Unifit to cool before scraping the Carbon Pad with a spatula.